


Installation Instructions:

Reinforce cracked masonry with 6mm (or 4.5mm for thin mortar joints)

1




GRIND AWAY EXISTING MORTAR.

Grind existing mortar 1-1/2" to 2" in depth and clean with water prior to installation



1-1/2" to 2"


2



APPLY A BEAD OF SUREGROUT S AT THE BASE OF THE GROUND JOINT.


SureGrout S preparation: Mix the two-part, ready-to-mix packs of powder with the provided admixture. Pour the liquid into the pail provided, pour the powder slowly into the pail, and mix with a paddle mixer for a full 2 minutes, ensuring that the powder is completely blended. (No additional water or powder should be added.) Once mixed, the grout is ready to be used and has a usability time of 45 minutes. Cover pail from direct sunlight.

3




INSERT STITCH-TIE BAR INTO BEAD OF SUREGROUT S.

4



APPLY SECOND/THIRD BEAD OF SUREGROUT S OVER STITCH-TIE BAR, and compact with appropriate trowel.

5



If an **ADDITIONAL REINFORCING** Stitch-Tie Bar is required, repeat steps 3 & 4. Compact with trowel when complete and allow enough room in slot to re-point with mortar.

for helical beaming applications

Additional Installation Notes:

1. When installing in a non-linear joint, the Stitch-Tie Bar can be bent to follow the mortar's path or even be turned 90 degrees, wrapping a corner.
2. For areas where multiple vertical cracks are in close proximity, extend the Stitch-Tie Bar 20" past the outermost cracks. Either a longer length coil could be used and cut to size, or shorter lengths can be lapped (providing a minimum 6" overlap).
3. For multi-wythe walls, where it is observed that the crack propagates through the full thickness, the wall should be repaired on both sides, if accessible.
4. SureGrout S can be re-agitated by re-mixing the remaining contents in the pail to achieve a blended consistency again. DO NOT add additional water.
5. Under no circumstances should the grout be used where freezing may occur within 24 hours. The grout performance may be impaired if not protected from freezing.
6. Suregrout S can be pointed after installation once thumb-print hard.
7. Coatings can be applied to Suregrout S after being allowed to cure for 24 hours.