



NOTE:
ADEQUATE DRAINAGE NEEDS
TO BE PROVIDED AT EACH
WINDOW FRAME SILL FLANGE.
R-GUARD FASTFLASH IS NOT
TO BE INSTALLED / APPLIED OVER
NAIL FLANGE AT SILL CONDITION.
INSERT WINDOW SHIM AT $\frac{1}{4}$ POINTS
OF WINDOW FRAME

S6.1 SEALING WINDOW FLANGES

SCALE: 3" = 1'-0"



PROSOCO

PROSOCO R-GUARD Details