



**NOTE:**  
ADEQUATE DRAINAGE NEEDS TO BE PROVIDED AT EACH WINDOW FRAME SILL FLANGE. R-GUARD FASTFLASH IS NOT TO BE INSTALLED / APPLIED OVER NAIL FLANGE AT SILL CONDITION. INSERT WINDOW SHIM AT  $\frac{1}{4}$  POINTS OF WINDOW FRAME

## **S6.1** SEALING WINDOW FLANGES

SCALE: 3" = 1'-0"



**PROSOCO**

**PROSOCO R-GUARD Details**