

Sheathing Wall Construction with gypsum, plywood or OSB sheathing.

Consolidate and seal the raw, cut gypsum board edges within the inside/outside wall corners by brushing on a thin uniform coat of **PorousPrep**.

Apply **FastFlash** or **Joint & Seam Filler** to all inside corners, fill outside corner joint with **Joint & Seam Filler**. Use a dry joint knife or trowel to spread 1 inch beyond seam and outer cut edge to a thickness of 20-30 mils.

Apply the selected R-Guard air and water-resistive barrier over the prepared sheathing wall.

