

R-Guard

AIR & WATER BARRIERS

Roof-To-Wall Transition - Wall Cap to Roof - S9.1

Sheathing Wall Construction with gypsum, plywood or OSB sheathing.

Apply **FastFlash** or **Joint & Seam Filler** to non-vented parapet sheathing wall seams and roof decking seams (see detail S1.1). Apply a thick bead of **FastFlash** or **Joint & Seam Filler** to the base of the parapet sheathing wall and roof deck interface. Use a dry trowel or spatula to tool and seal the joint. Create a profile that directs bulk water away from the joint. Allow to skin over.

Roller or spray apply **Cat 5** to the parapet sheathing wall and the roof decking to form an opaque, monolithic membrane over the sheathing and the roof deck, which is free of voids and pinholes.

