

R·Guard®

AIR & WATER BARRIERS

Rough Opening with FastFlash & Building Wrap S13.1

Sheathing Wall Construction with gypsum, plywood or OSB sheathing.

Begin with **FastFlash** applied as in S4.1A or **FastFlash** and **Joint & Seam Filler** applied as in S4.1B.

Step One Apply **AirDam** to the outer edge of the rough opening and tool to 20-25 wet mils.

Step Two Press building wrap into wet **AirDam**.

Step Three Apply **AirDam** at interface of building wrap and rough opening, and tool it to 20-25 mils, so that it half covers the building wrap and half overlaps into the rough opening.

