

CTP FAÇADE-TIE BRACKET INSTALLATION

(STITCH-TIE HELICAL ANCHORS)

SPACE ASSEMBLIES 16" x 16" MAXIMUM (unless otherwise specified)



STEP 1- Drill $\frac{1}{4}$ " hole through the sheathing approximately $\frac{1}{4}$ "– $\frac{3}{4}$ " from the stud face (parallel with mounting face) into brick or joint approximately 2" or greater.



STEP 4- Attach the Façade-Tie Bracket to the stud with the supplied hardware



STEP 2- Select a Stitch-Tie helical anchor equal to the distance from the stud face to the brick and install per Stitch-Tie installation requirements.



Installation Complete



STEP 3) Attach Façade-Tie Bracket to the Stitch-tie anchor.