

1.1 SHEATHING WALL SEAM

metal studs with gypsum sheathing/OSB sheathing/plywood

Spot over all fasteners with **FastFlash** or **Joint & Seam Filler**.

Apply a thick bead of **FastFlash** or **Joint & Seam Filler** to all sheathing joints.

Use a dry joint knife or trowel to spread 1 inch beyond the seam on each side to a minimum thickness of 12 mils (FastFlash) or 20 mils (Joint & seam Filler).

Follow sheathing manufacturer recommendations to repair joints or gaps greater than 1 inch.

Apply the selected PROSOCO primary air and water-resistive barrier over the prepared sheathing wall.

