

10.1

ROOF-TO-WALL TRANSITION – PARAPET WALL FACE

metal studs with gypsum sheathing/OSB sheathing/plywood

Consolidate and seal any raw, cut gypsum board edges by brushing or spraying on a thin uniform coat of **PorousPrep**.

Along the top edge of the non-vented parapet, apply **FastFlash** to the front face of sheathing and the structural member. Spread the wet product to create a seamless transition with the roofing membrane coming down the vertical face of the wall.

