

10.2

ROOF-TO-WALL TRANSITION – PARAPET WALL FACE

wood construction with plywood/OSB sheathing

Along the top edge of the non-vented parapet, apply **FastFlash** to the front face of sheathing and the structural member. Spread the wet product to create a seamless transition with the roofing membrane coming down the vertical face of the wall.

