

# 11.1 TERMINATION AT GRADE - STUCCO

## metal studs with gypsum sheathing/OSB sheathing/plywood

*\*Note: Below-grade waterproofing should be in place prior to application of an R-Guard membrane. Transition interface should be cleaned prior to air barrier application.*

Install non-gassing polyethylene foam backer rod (SofRod) into joint at foundation-to-wall interface. Apply enough **Joint & Seam Filler** to sufficiently fill the joint to allow for tooling of excess sealant onto the sheathing and the foundation waterproofing. Apply **FastFlash** to transition from foundation waterproofing approximately 2 inches on either side. DO NOT spread product beyond the flange edge of the weep screed.

Roller or spray apply the selected PROSOCO's Primary Air & Water Resistive Barrier over cured sealant and onto sheathing board in preparation to install weep screed. Seal top of vertical flange with a bead of **Joint & Seam Filler** or **FastFlash** and tool smooth.

Install paper-backed metal lath in preparation for the scratch coat application of stucco.

