

12.1 OPEN JOINT ONE INCH AND SMALLER

metal studs with gypsum sheathing/OSB sheathing/plywood

Limit the size of the deflection joint to no more than 1 inch in width for **FastFlash** use. Reference 12.3 for deflection joints greater than 1 inch.

Apply **PorousPrep** over raw edge of sheathing board. Install non-gassing polyethylene foam backer rod into joint opening in preparation to receive **Joint & Seam Filler**. Apply **Joint & Seamer Filler** into opening, over-filling the joint to provide enough material to tool excess on both sides of the joint, about 1 inch on either side.

After **Joint & Seam Filler** has skinned over, apply a 4-inch-wide application of **FastFlash** banding over the Joint & Seam Filler in a bridge-joint configuration.

After **FastFlash** has skinned over, apply the selected PROSOCO Primary Air & Water Resistive Barrier over entire joint.

