

## 2.2 INSIDE/OUTSIDE WALL CORNERS

wood construction with plywood/OSB sheathing

Apply **FastFlash** or **Joint & Seam Filler** to all inside corners, fill outside corner joint with **Joint & Seam Filler**. Use a dry joint knife or trowel to spread 1 inch beyond seam and outer cut edge to a minimum thickness of 12 mils (FastFlash) or 20 mils (Joint & seam Filler).

Apply the **selected R-Guard primary air and water-resistive barrier** over the prepared sheathing wall.

