

22.1 FLASHING TRANSITION - BASE OF WALL

SS ThruWall Flashing

Apply a thick bead of **FastFlash** or **Joint & Seam Filler** to the joint between the base of the wall and the foundation. Use a dry trowel or spatula to tool and seal the joint. Create a profile that directs bulk water away from the joint.

Trade sequencing may make wet-setting impractical, and it is not required. Apply a bead of **FastFlash** to the top edge of the termination bar. Use a dry trowel or spatula to tool and seal the joint. Create a profile that directs bulk water away from the joint. Allow product to skin over.

