

# 4.2 ROUGH OPENING

## wood construction with plywood/OSB sheathing

Apply **FastFlash** to all inside corners, joints and seams, and framing surfaces within the rough opening at a minimum of 12 mils.

Apply **FastFlash** over the framing inside the rough opening and the structural wall surrounding the rough opening. Use a dry joint knife, trowel or chipper brush to spread the wet product to create a seamless flashing membrane which protects the rough opening and extends a minimum of 4 inches over the face of the structural wall. Apply additional **FastFlash** as needed to create an opaque, monolithic flashing membrane free of voids or pinholes. Apply the selected R-Guard air and water-resistive barrier over the prepared sheathing at a minimum of 1" overlap of **FastFlash** or **Joint & Seam Filler** with PROSOCO's primary air and water resistive barrier.

