

4.5

ROUGH OPENING WITH FASTFLASH & BUILDING WRAP

metal studs with gypsum sheathing/OSB sheathing/plywood

Step One apply **FastFlash** or **Joint & Seam Filler** as shown in 4.1.

Step Two Cut existing building wrap way from rough opening a minimum of 2 inches.

Step Three Apply **AirDam** to the outer edge of the rough opening and tool to a minimum of 20 wet mils.

Step Four Press building wrap into wet **AirDam**.

Step Five Apply **AirDam** at interface of building wrap and rough opening, and tool it to a minimum of 20 mils, so that it half covers the building wrap and half overlaps into the rough opening.

