

All Purpose Cleaner

Drastically reduce the number of cleaning products you keep on hand. Enviro Klean® All Purpose Cleaner is a cleaner and degreaser that can be used on most washable household surfaces – inside and out. Perfect for cleaning common interior household surfaces including polished and unpolished stone, tile, vinyl, hardwood and laminate flooring, bathroom and kitchen fixtures, mirrors, switch plates, ceiling fans, blinds, walls, finished wood trim and furniture. Powerful enough to clean most exterior surfaces such as concrete, brick, stone, stucco, EIFS, siding, windows, painted and finished wood.

Enviro Klean® All Purpose Cleaner can also be used to clean most auto, ATV, RV and marine surfaces, including painted and unpainted metals, glass, fiberglass, plexiglas and other plastics, rubber, hulls, wheels, tires, engines, chassis, bilges and most car and boat interior surfaces* including water-safe upholstery. (*Not for use on suede or leather.)

Enviro Klean® All Purpose Cleaner is a US EPA Safer Choice certified cleaner that meets the Safer Choice direct release criteria and is safer for aquatic life and for direct release into the environment including oceans, seas, lakes, ponds, rivers, ditches, sewers, wetlands.



epa.gov/saferchoice

Enviro Klean® All Purpose Cleaner contains NO phosphates, hazardous solvents, parabens, petrochemicals, phthalates, sulfates, fragrance, colorants, dyes, alcohol, ammonia or bleach. Enviro Klean® All Purpose Cleaner was intentionally designed to be safer for use around people, plants, lawns, pets or wildlife.

ADVANTAGES

- US EPA Safer Choice certified cleaner. Meets Safer Choice direct release criteria.
- Meets the US EPA's Safer Choice criteria for indoor and outdoor use.
- Works on an enormous variety of surfaces, including in food processing facilities.
- Replaces a host of individual cleaning agents.
- Economical and effective concentrate solution. Dilutable with up to 30 parts water.
- Powerful, streak-free cleaning on glass, metal, wood, tile and other hard surfaces.
- Reduce plastic packaging waste. Save time and money.
- Contains no phosphates, hazardous solvents, or environmentally harmful surfactants.
- Fragrance free. Colorant free.
- Easy-to-use and water-rinsable.

SAFETY INFORMATION

Always read full label and SDS for precautionary instructions before use. Use appropriate safety equipment and job-site controls during application and handling.

24-Hour Emergency Information: INFOTRAC at 800-535-5053

REGULATORY COMPLIANCE

VOC Compliance

Enviro Klean® All Purpose Cleaner is compliant with all national, state, district, consumer and institutional product VOC regulations.



Nonfood Compounds A1 and A4

Product Data Sheet Enviro Klean® All Purpose Cleaner

TYPICAL TECHNICAL DATA

FORM	Clear liquid, mild odor
SPECIFIC GRAVITY	1.05
pН	10.90
WT/GAL	8.70 lbs
ACTIVE CONTENT	not applicable
TOTAL SOLIDS	not applicable
VOC CONTENT	0
FLASH POINT	>212° F (>100° C)
FREEZE POINT	32° F (0° C)
SHELF LIFE	2 years in tightly sealed, unopened container

PREPARATION

Before use, test all surfaces not intended to be cleaned. If testing indicates adverse effects, the surface must be protected before full scale application. Best practice is to protect people, vehicles, property, metal, painted surfaces, plants and other non-target surfaces from product, splash, residue, wind drift and fumes.

Surface and Air Temperatures

Best air and surface temperatures for cleaning are 50° F (10° C) or above. Cleaning when temperatures are below freezing or will be overnight may be harmful. If freezing conditions exist before application, allow surface to thaw before application.

Equipment

Apply with low-pressure sprayer or brush. Scrub heavily soiled surfaces with a nonabrasive brush. On sensitive surfaces, use a soft-bristle brush or sponge to agitate.

When cleaning glass, use a clean, dry paper towel or lint-free cloth.

Rinse with enough clean water to flush spent cleaner and dissolved soiling from the surface without damage.

Storage and Handling

Shelf life assumes upright storage of factory-sealed containers. Store in cool, dry place maintaining temperature of 45–100°F (7–38°C). Always seal container after use. Do not alter or mix with other chemicals. If product freezes, allow to thaw and mix well. Dispose of unused material in accordance with local, state and federal regulations.

APPLICATION

Read "Preparation" and the Safety Data Sheet before use. ALWAYS TEST a small area of each surface to confirm suitability, coverage rate and desired results before beginning overall application. Test with the same equipment, recommended surface preparation and application procedures planned for general application. Let surface dry thoroughly before inspection.

Dilution

Do not alter or use for purposes other than specified. Always test to final dilution producing desired results.

- For general purpose cleaning, dilute up to 1:10 with clean water. Example: 1 fl.oz. cleaner + 10 fl.oz. clean water
- For glass cleaning, dilute 1:30 with clean water, approximately 4 oz cleaner + 1-gal clean water.
- Use in concentrate to remove heavy soiling.

Application Instructions

- 1. Prewet the surface with clean water. On vertical surfaces, work from the bottom to the top.
- 2. Apply the cleaner to the prewet surface using a brush or low-pressure spray.
- 3. Allow the cleaner to dwell on the treated surface for 1–10 minutes, based on testing. Gently scrub heavily soiled areas. *NOTE*: DO NOT let the cleaner dry on the surface. If drying occurs, lightly wet the surface with clean water and reapply the cleaner in a gentle scrubbing manner.
- 4. Always rinse cleaned surfaces thoroughly with clean, fresh water. On vertical surfaces, rinse from the bottom to the top.
- 5. Allow cleaned surfaces to dry.
- 6. Repeat steps 1 through 5, if necessary.

GLASS CLEANING

Dilute All Purpose Cleaner with 30 parts water, approximately 4 oz cleaner per 1-gallon of clean water. Using a trigger sprayer or other low-pressure sprayer, spray surface with cleaner. Wipe up cleaner with dry paper towel or lint-free cloth.

Cleanup

Clean tools and equipment with fresh water.



Product Data Sheet Enviro Klean® All Purpose Cleaner

Ingredient Disclosure

Ingredient	CAS #	
Water	7732-18-5	
Alanine, N, N bis (carboxymethyl)-		
trisodium salt	164462-16-2	
Proprietary surfactant blend	Proprietary	
Sodium xylene sulfonate	1300-72-7	
Citric Acid	77-92-9	

WARRANTY

The information and recommendations made are based on our own research and the research of others, and are believed to be accurate. However, no guarantee of their accuracy is made because we cannot cover every possible application of our products, nor anticipate every variation encountered in masonry surfaces, job conditions and methods used. The purchasers shall make their own tests to determine the suitability of such products for a particular purpose.

PROSOCO, Inc. warrants this product to be free from defects. Where permitted by law, PROSOCO makes no other warranties with respect to this product, express or implied, including without limitation the implied warranties of merchantability or fitness for particular purpose. The purchaser shall be responsible to make his own tests to determine the suitability of this product for his particular purpose. PROSOCO's liability shall be limited in all events to supplying sufficient product to re-treat the specific areas to which defective product has been applied. Acceptance and use of this product absolves PROSOCO from any other liability, from whatever source, including liability for incidental, consequential or resultant damages whether due to breach of warranty, negligence or strict liability. This warranty may not be modified or extended by representatives of PROSOCO, its distributors or dealers.