

### SS ThruWall Flashing

Apply a thick bead of **FastFlash** to the joint between the base of the wall and the foundation. Use a dry trowel or spatula to tool and seal the joint. Create a profile that directs bulk water away from the joint.

Apply a bead of **FastFlash** along the top of the upper vertical edge of the **SS ThruWall** flashing. Wet-set the termination bar. Mechanically fasten the termination bar.

Trade sequencing may make wet-setting impractical, and it is not required.

Apply a bead of **FastFlash** to the top edge of the termination bar. Use a dry trowel or spatula to tool and seal the joint. Create a profile that directs bulk water away from the joint. Allow product to skin over.

To transition from the air- and water-resistive barrier to the **SS ThruWall** flashing, apply a bead of **FastFlash** immediately above and below the top edge of the termination bar. Use a dry joint knife or trowel to spread the wet product to create a seamless counter-flashing membrane which directs bulk water from the air- and water-resistive barrier to the **SS ThruWall** flashing. Apply additional **FastFlash** as needed to create an opaque, monolithic flashing membrane free of voids or pinholes.

