

15.1 OVERLAP/SPLICE JOINT OF SURESPAN EX

gypsum sheathing/OSB sheathing/plywood

Apply a 3/8-inch bead of SureSpan Adhesive on both sides of the joint. The 3/8-inch bead will spread to a width of 1/2 inch (minimum 20 mils thick). Sealant coverage may vary depending on the porosity or texture of substrate.

Place the **SureSpan EX** into the wet sealant using hand pressure to adequately spread the **SureSpan Adhesive** onto the extrusion. Small adjustments to the placement of the **SureSpan EX** may be done at this time, but lifting and re-seating should be avoided and may result in needing additional **SureSpan Adhesive** installed to fully engage the extrusion into the wet sealant. Use a small roller such as a laminate roller to apply sufficient pressure to set the **SureSpan Adhesive**.

Vertical joints should be overlapped a minimum of one inch. If mitered or field-cut corners are used, apply enough sealant under the corner joint so the excess sealant fills the miter joint.

Prior to tooling the excess **SureSpan Adhesive** alongside the extrusion, gun an additional 1/4-inch bead of **SureSpan Adhesive** to smooth out and counterflash the exposed edge of the extrusion 3/4 of an inch. Tool excessive sealant immediately.

